




Chemical Resistant, Bund Lining



1. Surface preparation by suitable mechanical means. Repair concrete defects with Remmers concrete repair systems.
2. The prepared substrate is primed with Epoxy FAS100 by roller.
3. Application of intermediate coat of Epoxy CR Color.
4. Application of top coat of Epoxy CR Color.
5. Optional slip resistant walkway.





System Properties:

- Highly chemical resistant
- Solvent Free
- Wide range of colours
- Waterproof
- Slip resistance available
- Easy to clean
- High film thickness
- East to apply
- Bund lining

Typical Environment

	Light Loads	✓
	Moderate Loads	✓
	Increased Loads	✓
	Heavy Loads	✗

Suitable for Surfaces

Repaired surfaces	
Steel ball blasted surface	
Ground surfaces	
Concrete slabs	



Chemical Resistant, Bund Lining

Item	Operation	Material / m ²
1	Surface Preparation The substrate shall be prepared by suitable means to remove all contaminants and weakness to give a clean, sound load-bearing surface. If over coating an existing finish a trial shall be conducted to assess bond. Any defects to concrete should be repaired. Please contact Remmers for advice.	
2	Priming The substrate is primed using FAS 100.	0.3 – 0.5 kg/m ²
3	Intermediate Coat The primed surface is coated with Epoxy CR Color.	0.5 kg/m ²
4	Top Coat The intermediate coat is sealed with a further coat of Epoxy CR Color	0.5 kg/m ²
5	Optional Slip Resistant Walkway Apply a further coat of Epoxy CR Color in a contrasting colour by trowel or squeegee. Follow with a scatter of a medium Quartz and back roller.	0.5 kg/m ²
Total		

Notes: Application rates and coverage are theoretical and do not allow for surface profile variation, wastage or variation in application technique. In the case of high substrate roughness you should allow for additional levelling material to be used.